



**M12 FUEL**  
**DIGITAL TORQUE WRENCH**

**QUICK START GUIDE**

# TABLE OF CONTENTS

How to Use .....	2
Adjusting Target Torque .....	3
Adjusting Torque Range .....	4
Adjusting Rundown Torque .....	5
Setting Unit of Measure .....	6


- 1) Set Target Torque
- 2) Pull trigger to max RPM
- 3) Tool will automatically stop prior to Target Torque to prevent over torquing
- 4) Finish by hand to reach Target Torque




- 5) Press  to save record

# ADJUSTING TARGET TORQUE


**Target Torque is the required torque value for the fastener being installed. Adjust the target torque to meet the desired torque specifications.**



Navigate to Target Torque and press OK




Adjust the Target Torque using UP▲/DOWN▼




Press OK when finished

# ADJUSTING TORQUE RANGE


**Torque Range indicates the acceptable range of values for a successful install event.  
Adjust the Torque Range to meet the recommended torque specifications.**



Navigate to Range and press OK




Adjust the Torque Range using UP▲/ DOWN▼




Navigate to Done and press OK when finished

# ADJUSTING RUNDOWN TORQUE

**Rundown Torque changes the tool's power output.  
Adjust the Rundown Torque to help  
prevent over torquing of the fastener.**



Navigate to top left corner and press OK to go to Menu




Navigate to Rundown Torque in Menu and press OK




Use UP▲/DOWN▼ to select tool's Rundown Torque and press OK

# SETTING UNIT OF MEASURE


**Adjust the unit of measure to comply with the required torque specifications of the fastener.**



Navigate to  
Settings in Menu  
and press OK



Navigate to  
Units in Settings  
and press OK



Select desired  
Unit and press OK

