

blue  
by Blueair

Air purifier /  
공기 청정기



blue  
by Blueair

User Manual / 사용 설명서

Blue  
PURE 211

# Blue PURE 211

English User Manual  
Pure 211

English User Manual  
한국어 사용자 설명서

03 -18

19 - 34

SAFETY	04
SYSTEM OVERVIEW	06
WHAT'S IN THE BOX	08
USAGE	09
SETUP	10
ON/OFF AND OPERATING SPEEDS	11
FILTERS	12
CARE AND MAINTENANCE	17
SPECIFICATIONS	18

# General safety instructions

Remember, Pure 211 is an electrical appliance. Please read these safety instructions carefully before use and take the necessary precautions to reduce the risk of fire, electric shock or injury. **The Pure 211 warranty applies only if the unit is used according to these instructions.**



**WARNING:** Indicates a hazardous situation that, if not avoided, could result in death or serious injury.



**CAUTION:** Indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

## General



**WARNING:**  
To avoid hazardous conditions, only the manufacturer, a service center authorized by Blueair or similarly qualified persons shall replace the power cord, if damaged.



### CAUTIONS:

- Use the grounded power cable provided with your Pure 211 unit to plug directly into an appropriate, grounded electrical outlet. (Refer to the rating label on your unit).
- Do not alter the plug in any way.
- Remember to always disconnect the power supply before servicing the unit.
- Do not use the unit if the power cable or plug is damaged or malfunctions in any manner.


- Keep the power cable away from heated surfaces.
- Do not sit on, stand or climb onto the unit or use the unit either as a table or for storage.
- Do not place any objects on top of the unit, block air outlets or intakes, or allow foreign objects to enter the unit as this may cause an electric shock or damage the unit.

## Intended Use



### CAUTIONS:


- Supervise children to ensure that they do not play with the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.




## Blueprint

- ① Air outlet
- ② Ion chamber (Air stream optimizer)
- ③ Inner wall
- ④ Fan
- ⑤ Motor
- ⑥ Fan base
- ⑦ Protective grill
- ⑧ Release button for filter
- ⑨ Pre-filter
- ⑩ Particle filter or Particle + Carbon filter
- ⑪ Air inlet 360°

## Pure 211 package



The Pure 211 air purifier



Particle or Particle + Carbon filter



Fabric pre-filters  
(Two filters included)

## Options

- A Particle filter or Particle + Carbon filter.
- Choice of color for the fabric pre-filter.

## Placement

Place Pure 211 in an upright position on the floor in your room. Be sure to place the unit where it won't be knocked over by any person or pet in the household.

### Using Pure 211 in your bedroom:

After 7 seconds the light automatically dims to 10% of the full effect.

### Placing the unit:



Place the unit in a location where air can circulate freely in, out and around the unit.



Do not place the unit near sources of heat, such as radiators, fireplaces or ovens.



Do not place the unit closer than 10 cm (4") from another object.



Do not place the unit near wet areas, such as bathrooms or laundry rooms where it may come into contact with water.




Do not place the unit directly on or against soft furnishings such as bedding or linen.




Do not place the unit outdoors.

## Getting started




1 Gently press the buttons on both sides of the unit simultaneously.




2 Remove the top portion of the unit.




3 Then attach the fabric pre-filter. To ensure a smooth fit, pull it carefully over the main filter.



4 Next, reposition the top of the unit onto the bottom and make sure it clicks into place.




5 Plug in your Pure 211 air purifier.




6 Press the button to turn the unit on. The unit automatically sets itself to the recommended energy-efficient operating speed.


## On/off and speed control




1 **On/Low**  
Press once to turn the unit on and set it to the recommended energy-efficient speed.



2 **Medium**  
Press twice to set to medium speed.



3 **High**  
Press three times to set to high speed.



4 **Off**  
Press a fourth time to turn the unit off.

Moreover, Pure 211 has an Autostart feature. This means that Pure 211 will automatically restart at the set speed if a power failure occurs, the unit is unplugged or a power switch timer is used.

# Filters

## General information:

The unit is delivered with two fabric pre-filters and either a Particle filter or Particle + Carbon filter. These filters remove the following pollutants:

### Particle filters remove:



PM2.5\*



Dust



Pollen



Pet dander



Mold



Dust mites



Bacteria

### Particle + Carbon filters remove all the above pollutants, plus:



VOC



Smoke




Chemicals




Cooking odors

\*Particle matter smaller than 2.5 microns


## Button control functions



**Change filter indicator**  
When the indicator turns yellow (after 5 months of operation), it's time to order a new filter.



**Change filter**  
When the indicator light turns red (after 1 extra month of operation), you should change the main filter.



**Reset filter alert**  
Press the button for three seconds to reset the filter alert.

You can change the filter before the indicator light turns red, i.e. when it first turns yellow. In this case, just reset the unit after changing the filter and use for another 6 months. (see "Change the main filter")


### IMPORTANT!

Use only genuine Blueair filters to ensure proper function of your unit and to qualify for full warranty coverage.


## Vacuum or wash the pre-filter

Occasionally vacuum the exterior of the fabric pre-filter to remove dust.


Before removing the fabric pre-filter, unplug the unit.




1 Gently pull and detach the pre-filter from the lower half of the unit.



2 Wash the pre-filter on a gentle, low temperature cycle in the washing machine.




3 Before re-replacing the fabric pre-filter, gently press the release buttons on both sides of the unit until you hear a click.



4 Lift off the top of the unit.



5 Re-fit the fabric pre-filter over the bottom part of the unit.



6 Replace the top of the unit, pressing firmly until you hear a click.


Plug in the unit and touch the button to restart.

## Change the main filter


Be sure to unplug the unit before changing the main filter.




1 When the indicator light glows red, it's time to change the main filter.




2 Turn off the unit and unplug it.




3 Gently press the release buttons on both sides of the unit until you hear a click.



4 Lift off the top of the unit.




5 Gently pull and detach the fabric pre-filter from the old main filter and fit the pre-filter onto the new main filter.




6 Firmly press the top of the unit onto the replacement filter until you hear a click.






Plug in the unit.



Restart the unit by pressing the Pure 211 button for three seconds, and then release it.



This lets Pure 211 know that you have changed the filter. The indicator light flashes 3 times and then changes from red to white.

## General care

Take good care of your Pure 211 air purifier to ensure that it delivers optimal performance.

- Vacuum the pre-filter occasionally to remove dust, or wash it on a gentle, low temperature cycle in the washing machine.
- Change the main filter every six months, depending on the operating conditions.
- When the unit is open to change the filter, vacuum any dust that may have accumulated inside the unit.
- Occasionally wipe the top of the unit with a dry dust cloth.

# Specifications<sup>1</sup>

Room size:	50m <sup>2</sup> (540 sq. ft.)		
Clean Air Delivery Rate (CADR)	Smoke	Dust	Pollen
	cfm	350	350
	m <sup>3</sup> /h	590	590
Filter replacement indicator	Yes		
On/Off timer	No		
Speeds	1-2-3-off		
Dimensions	Height:	517 mm (20.4 in)	
	Width:	330 mm (13 in)	
	Depth:	330 mm (13 in)	
	Weight:	5.7 kg (13 lbs)	
Airflow rate	230 - 620 m <sup>3</sup> /h (135 - 365 cfm)		
Air exchange <sup>2</sup>	5 per hour (50 m <sup>2</sup> or 540 sq.ft.room)		
Power usage <sup>4</sup>	30 - 61 W		
Noise level	31 - 56 dB(A)		
Average filter service life	six months <sup>3</sup>		
Warranty	Local regulations		

Blue is available in different colors for model Pure 211. The colored fabric works as a pre-filter.

<sup>1</sup>Certified ratings as stated are based on U.S. version models (120VAC, 60Hz) with Blue Particle Filter. Ratings may be affected by use of other Blue filter models.

<sup>2</sup>Air changes per hour are calculated on the recommended room size, assuming 8-foot (2.4-m) ceilings. For smaller rooms, the air changes per hour will increase.

<sup>3</sup>Depending on air quality in the area of use, the recommended six-month filter lifetime may be longer.

<sup>4</sup>The available electrical power voltage and frequency affects the power consumption of the unit. the power consumption might therefore be different from the stated value.

# Blue PURE 211

사용 설명서(한국어)  
모델: Pure211

안전 관련 사항	20
시스템 개요	22
구성품	24
사용법	25
설정	26
전원 ON/OFF 및 속도 제어	27
필터 S	28
관리 및 유지보수	33
사양	34

## 일반 안전 지침

기억하세요, Pure 211는 전기 제품입니다. 사용 전에 안전 지침을 자세히 읽어 보고, 화재, 감전 또는 부상의 위험을 줄이기 위해 필요한 예방조치를 취하십시오. **Pure 211 보증은 이런 지침에 따라 이 제품 사용했을 경우에만 적용됩니다.**



**경고:** 예방하지 않을 경우 사망 또는 심각한 부상을 초래할 수 있는 위험한 상황을 나타냅니다.



**주의:** 예방하지 않을 경우 중경상을 초래할 수 있는 위험한 상황을 나타냅니다.

### 일반 사항



**경고:** 위험을 방지하기 위해서 손상된 공급 케이블은 항상 블루가 승인한 제조업체, 서비스 대행업체 또는 유사한 자격을 갖춘 기술자가 교체해야 합니다.



- 경고:**
- Pure 211 장치와 함께 제공된 접지 전원 케이블을 사용하여 해당하 는 접지 전기 콘센트에 직접 꽂으십시오(장치의 정격 라벨 참조).
  - 이 플러그는 절대로 개조하지 마십시오.
  - 이 제품을 수리하려면 반드시 전원을 차단하십시오.
  - 전원 코드나 플러그가 손상된 경우 또는 오작동하거나 파손된 경우, 이 제품을 사용하지 마십시오.

- 전원 코드는 열이 나는 곳에서 멀리 두십시오.
- 이 제품 위에 앉거나, 서거나, 올라가면 안되며, 테이블로 사용하거나 물건을 올려 놓지 마십시오.
- 이 제품 위에 어떤 물건도 올려 놓으면 안되며 공기 배출구나 흡입구가 막히지 않도록 해야 하고, 감전 또는 제품이 손상될 수 있으므로 이물질이 제품 안으로 들어가지 않도록 하십시오.


### 주의 사항



#### 주의:

- 어린이가 기기를 가지고 놀지 않도록 지도해 주십시오.
- 이 제품은 신체 장애, 정신 지체자를 비롯하여 경험이나 지식이 부족한 사람(어린이 포함)은 사용할 수 없으며 이러한 사용자가 제품 사용과 관련된 감독이나 지침을 제공받지 않은 경우 안전 관련 책임은 사용자에게 있습니다.

## 블루프린트




- ① 공기 배출구
- ② 이온 챔버 (기류 최적화 장치)
- ③ 내벽
- ④ 팬
- ⑤ 모터
- ⑥ 팬 받침
- ⑦ 보호용 그릴
- ⑧ 필터 분리 버튼
- ⑨ 패브릭 프리필터
- ⑩ 파티클 필터 또는 콤비네이션 필터
- ⑪ 360° 공기 흡입구

## Pure 211 패키지



공기 청정기 Pure 211



파티클 또는 콤비네이션 필터



패브릭 프리필터 (필터 2개 포함)

## 옵션 및 추가 장치

- 활성탄 필터와 파티클 필터로 구성된 결합 필터
- 세련된 패브릭 프리필터 채택

## 제품 배치의

실내 바닥에 Pure 211을 세워 놓습니다. 사람이나 애완동물에 의해 제품이 넘어지지 않도록 기기를 놓아야 합니다.

### 실내에서 블루를 사용하십니까?

걱정하지 마십시오. 7초 후 표시등이 자동으로 최대 밝기의 10%로 흐리게 바뀝니다.

### 제품 배치의



공기가 제품 내외부와 주변에서 자유롭게 순환할 수 있는 위치에 장치를 **놓으십시오**.



라디에이터, 벽난로, 오븐 등과 같은 열원 근처에는 장치를 놓지 **마십시오**.



다른 물체와 4"(10 cm) 범위 안에는 장치를 놓지 **마십시오**.



욕실이나 세탁실과 같이 물과 닿을 수 있는 습기가 있는 곳 근처에는 장치를 놓지 **마십시오**.




침구나 이불 등 부드러운 소재의 비품에 기대거나 그 위에 장치를 놓지 **마십시오**.




실외에 장치를 놓지 **마십시오**.


## 시작하기




1 제품 양면에 있는 분리 버튼을 천천히 누릅니다.




2 제품 상단부를 들어 올려 분리합니다.




3 패브릭 프리필터를 장착하십시오. 패브릭 프리필터의 표시된 부분을 기본 필터의 상단 모서리 부분에 맞추면 편리하게 장착할 수 있습니다.



4 찰칵 소리가 날 때까지 제품 상단부를 하단부의 필터 쪽으로 단단히 누릅니다.




5 Pure 211 공기 청정기의 플러그를 끼웁니다.




6 버튼을 터치하여 제품을 켭니다. 권장되는 에너지 절약 작동 속도로 자동으로 설정됩니다. 설치가 끝났으며, 깨끗한 공기를 즐기십시오!


## ON/OFF 및 속도 제어




1 ON/저속  
한 번 터치하면 제품이 켜지며 권장되는 에너지 절약 속도로 설정됩니다.



2 중간 속도  
두 번 터치하면 중간 속도로 설정됩니다.



3 고속  
세 번 터치하면 고속으로 설정됩니다.



4 OFF  
한 번 더 터치하면 제품이 꺼집니다.

또한 Pure211에는 자동 시작 기능이 있습니다. 즉, Pure 211는 전원 문제 발생 시, 제품 플러그가 분리된 경우 또는 전원 스위치 타이머가 사용된 경우 설정된 속도로 자동으로 재시작됩니다.

# 필터

## 일반 정보

기기는 파티클 또는 콤비네이션(파티클+활성탄) 필터가 장착된 상태로 배송됩니다.

이런 필터는 다음과 같은 오염 물질을 걸러냅니다:

### 파티클 필터 제거:



PM2.5\*



먼지



오염물



애완동물 비듬



곰팡이



먼지 벌레



박테리아

콤비네이션(파티클+활성탄) 필터는 상기 모든 오염 물질과 다음을 걸러냅니다:



VOC



연기



화학물질




요리로 인한 냄새

\*2.5 마이크로미터 미만의 미립자


### 중요!

장치의 올바른 기능을 보장하고 전체 보증 범위를 적용 받으려면 정품 Blueair 필터만 사용하십시오.

## 버튼 제어 기능



**필터 교체 표시등**  
표시등이 노란색(5개월 가동 후)으로 켜지면 새 필터를 주문해야 합니다.



**필터 교체**  
표시등이 빨간색(1개월 더 가동 후)으로 켜지면 기본 필터를 교체해야 합니다.




**필터 경고 인식**  
버튼을 3초 동안 누르면 필터 경고가 인식됩니다.

표시등이 빨간색으로 바뀌기 전에 필터를 교체할 수 있습니다(노란색으로 처음 바졌을 때 등). 이 경우 필터를 교환한 후 기기를 재설정하고 다시 6개월간 사용하시면 됩니다. ("기본 필터 교체" 참조)


## 프리필터 진공청소 또는 세척

가끔 패브릭 프리필터의 외부를 진공청소기로 청소하여 먼지를 제거하십시오.


패브릭 프리필터를 제거하기 전에 플러그를 분리하십시오.




제품 하단부에서 프리필터를 천천히 당겨 빼십시오.



세탁기에서 저온의 물로 프리필터를 여러 번 가볍게 세척하십시오.




패브릭 프리필터를 교체하기 전에 제품 양면의 분리 버튼을 찰칵 소리가 날 때까지 천천히 누르십시오.



제품 상단부를 들어 올리십시오.




패브릭 표시부를 상단 구석에 맞추고 제품 하단부 위에 패브릭 프리필터를 다시 장착합니다.




제품 상단부를 찰칵 소리가 날 때까지 단단히 누르면서 다시 장착합니다.

## 기본 필터 교체


기본 필터 교체 시 기기 전원을 꺼야 합니다.




빨간색 표시등이 켜지면 기본 필터를 교체해야 합니다.




제품을 끄고 플러그를 뽑습니다.




제품 양면의 분리 버튼을 찰칵 소리가 날 때까지 천천히 누르십시오.



제품 상단부를 들어 올리십시오.




기존 기본 필터에서 패브릭 프리필터를 천천히 당겨 분리한 후 프리필터를 새 기본 필터에 장착합니다.




찰칵 소리가 날 때까지 제품 상단부를 교체용 필터 쪽으로 단단히 누릅니다.






제품의 플러그를  
꺼웁니다.



제품을 다시 시작하려면,  
Pure 211 버튼을 3초간  
누른 다음 놓습니다.



이렇게 하면 Pure  
211에서 필터 교체가  
인식됩니다. 표시등이 3  
번 깜박거린 후 빨간색이  
흰색으로 바뀝니다.  
끝났습니다!

## 일반적인 관리 방법

Pure 211 공기 청정기를 최상의 상태에서 사용하려면 올바르게 관리해야 합니다.

- 먼지를 제거하기 위해 프리필터를 자주 진공 청소하거나 세탁기에서 낮은 온도로 천천히 세척하십시오.
- 기본 필터는 가동 조건에 따라 6개월마다 교체하십시오.
- 필터 교체를 위해 제품을 연 경우, 내부에 쌓여 있는 먼지를 진공청소기로 제거하십시오.
- 가끔 마른 천으로 제품 상단을 닦아 주십시오.

# 사양<sup>1</sup>

권장 사용 면적	50m <sup>2</sup>			
CADR	연기 cfm m <sup>3</sup> /h	연기 350 590	먼지 350 590	오염물 350 590
필터 교체 표시기	있음			
On/Off 타이머	없음			
속도	1-2-3-off			
크기	높이:	517 mm (20.4 in)		
	너비:	330 mm (13 in)		
	깊이:	330 mm (13 in)		
	무게:	5.7 kg (13 lbs)		
풍속	230 - 620m <sup>3</sup> /h (135 - 365 cfm)			
시간당 공기 순환 횟수 <sup>2</sup>	5회 (50m <sup>2</sup> 크기의 방)			
소비 전력 <sup>4</sup>	30 - 61 W			
소음	31 - 56 dB(A)			
필터 평균 수명	6개월 <sup>3</sup>			
보증	2년			

Pure 211 모델의 경우 Blue는 다양한 컬러로 준비되어 있습니다. 컬러 패브릭은 프리필터로 가능합니다.

<sup>1</sup> 표시된 인증 정격은 Blue 파티클 필터가 장착된 미국 버전 모델(120VAC, 60Hz)을 기준으로 합니다. 정격은 다른 Blue 필터 모델을 사용하는 경우 달라질 수 있습니다.

<sup>2</sup> 시간 당 공기 순환 횟수는 천장 높이를 2.4m(8피트)로 가정할 때, 권장된 실내 크기에 따라 계산됩니다. 방이 작으면 시간 당 공기 순환 횟수가 증가합니다.

<sup>3</sup> 장치를 사용하는 환경의 공기 질에 따라 권장된 6개월의 필터 사용 시간은 더 길어질 수 있습니다.

<sup>4</sup> 사용 가능 전압 및 주파수에 따라 장치의 전력 소비량이 달라집니다. 따라서 전력 소비는 표시된 값과 다를 수 있습니다.



[www.blueair.com](http://www.blueair.com)  
[www.blueair.com/contact-us](http://www.blueair.com/contact-us)

**Blueair AB**

Karlavägen 108  
115 26 Stockholm  
Sweden  
Tel: +46 8 679 45 00

**Blueair AB Middle East**

Jafza One  
Office No. AB1503  
Jebel Ali Free Zone  
P.O. Box No. 263947  
Dubai  
+971 (4)8821244

**Blueair Inc.**

Suite 1900  
100 N LaSalle Street  
Chicago, IL 60602  
Tel: +1 888 258 3247

**Blueair India Pvt. Ltd.**

Embassy of Sweden  
Nyaya Marg, Chanakyapuri  
New Dehli - 110021  
Tel: +91 11 4606 7121

**Blueair (Shanghai) Trading  
Co. Ltd.**

Rm 1005 City Gateway  
No. 398 North Caoxi Road  
Xuhui Distr, Shanghai  
Tel: +86 21 6091 0981